



TQC Sheen Bresle Patch

LD6515

Better shape, better formula, stronger and clean.

The TQC Sheen Bresle Patch conforms to ISO 8502-6. It is a round self-adhesive plastic patch with a medical grade membrane and a known surface area. Due to the round shape it is stronger, whilst at the same time the patch has a clean removal, negligible patch contamination, no breaking foam and is silicon free. Each patch is certified and traceable. This unique Bresle patch is used by global coating industry leaders.

Bresle Method

Bresle patches are used to test for surface contaminants, such as salts. The patch is described in ISO 8502-6 and -9, also known as the Bresle Method. This Bresle Method is commonly used to measure the level of surface salts prior to coating.

Prevent maintenance costs

A too high level of salts may cause coating failures like blistering and corrosion. This might cause major problems and increase maintenance costs for shipping, vessels, ballast tanks, oil and gas piping, industry buildings and steel structures in general. Making salt level measurements prior to coating essential.

Features

- Strong
- Clean removal
- Negligible patch contamination
- No breaking foam
- Silicone free
- Test area is equal to the old patch (A1250)
- Meets ISO 8502-6 specifications
- Certified and traceable

Standards

ISO 8502-6, ISO 8502-9

Disclaimer

The information contained in this document is liable to modification from time to time in the light of experience and our policy of continuous product development. Check the Industrial Physics website for the latest version.

Scope of supply

- Bresle Patches, 25 pcs
- Needle
- Certificate
- Pictorial manual

Ordering Information:

Catalog Number Article Description

LD6515	Bresle Patches, 25 pcs
--------	------------------------

Accessories/Optional Items:

Catalog Number Article Description

SP7310	Bresle Kit
SP7930	Syringe and needle

Technical Specification:

Size: Ø 55 mm/2,17 in + tab 15 mm/0,59 in

Sample volume: 2,5 ml

Test area: 1250 mm² (1,94 in²)

Stress test: Meets ISO 8502-6 Annex A

Elastic film: Latex

Tape: PE with acrylic based adhesive

Protective paper: Coated

Special care

For a correct execution of the test only needles as specified in ISO 8502-6 should be used. The above specified needle SP7930 meets this standard. Store Bresle Patch in a cool and dark place. Keep Bresle Patch away from direct sunlight.

Contact Details

web. www.industrialphysics.com

email. info@industrialphysics.com

email. info.china@industrialphysics.com